

Validation Platform to Characterize Standalone Oscillators in Various Package Sizes

Harish Ramesh, Sambit Panda, Akhil Singh Texas Instruments India Pvt. Ltd.





Mesa, Arizona • March 3-6, 2024

OUTLINE

- Introduction
- TIs BAW Oscillator
- Importance of Validation
- Single Site vs Multi Site Test
- Different Multi Site Test Solutions
- Results
- Conclusion



Validation Platform to Characterize Standalone Oscillators in Various Package Sizes

25 NOVERSARY

INTRODUCTION

- Every complex system requires a timing and clocking subsystem for proper system functionality
- Standalone oscillators / crystals are basic building blocks
- Oscillators are available in
 - various package types
 - package size
 - pin count
 - wide range of frequencies




Validation Platform to Characterize Standalone Oscillators in Various Package Sizes

}



TIS BAW BASED OSCILLATORS

- Texas Instruments' **Bulk-Acoustic Wave (BAW)** is a micro-resonator technology that enables integration of high-precision BAW resonator directly into packages with ultra-low jitter clock circuitry
- TIs products
 - LMK6x Ultra Low Jitter, Differential and Single Ended Oscillators 2 packages In Production
 - CDC6C Low Power (5mA Active, 2uA SB), LVCMOS Oscillators 4 packages Evaluation Samples
- The device is **factory programmed** per specific operation mode, including frequency, voltage, output type, and function pin.



Validation Platform to Characterize Standalone Oscillators in Various Package Sizes

IMPORTANCE OF BENCH VALIDATION

- Oscillator performance is critical to meet the timing requirement in a system
- Requires extensive characterization of all parameters across several devices to guarantee spec in datasheet
 - Jitter / Phase Noise
 - Power Consumption
 - Output Driver Time Domain Characteristics
 - Aging
 - Overall Frequency Stability across Temperature
 - Power Up Transients
 - PSRR
 - Enable / Disable Time
 - Vibration / Mechanical Shock



Validation Platform to Characterize Standalone Oscillators in Various Package Sizes



IMPORTANCE OF BENCH VALIDATION

- Limited set of parameters can get tested on ATE / Production Test
 - Test Hardware and resource constraints
 - Test Time
- Oscillators is a high volume market
 - Demands statistical data from bench (Large sample characterization)
 - Aim is to ensure quality parts are released
 - No customer returns
- In this paper we talk about different validation platforms used in characterizing TIs BAW oscillators and Silicon Results



Validation Platform to Characterize Standalone Oscillators in Various Package Sizes

25 INDIFESTORIAL PROPERTY OF THE PROPERTY OF T

Session 3

SINGLE SITE V/S MULTI SITE TEST

- Single Site Setup for <u>high performance</u> and <u>test setup dependent</u> parameters
 - Phase Noise, PSRR, Vibration, Enable / Disable Time, Output Driver Charetc..
 - Device Count is limited to 10 to 15 units
 - Requires high end equipment (FSWP / E5052B) & passive hardware like
 Bias-Tee, High Z Probe for characterization
- Multi Site Setup for getting statistical data
 - Aging, Frequency stability, Final Trims, DC parameters etc..
 - Device count is ~50 to 200
 - Single Setup with higher coverage




Validation Platform to Characterize Standalone Oscillators in Various Package Sizes

•



SINGLE SITE TEST SETUP

- Validate performance of one device at a time with precision and quality
- Clock Output lines are impedance controlled and trace lengths are short to minimize trace loss, preserve signal integrity, reduce switching current (in case of LVCMOS)
- Flexibility in testing several termination options for various output drivers














Validation Platform to Characterize Standalone Oscillators in Various Package Sizes


MULTI SITE TEST SETUP

each device

Single Package with 64 sites



Mother Board + Daughter Card Setup




Mother Board with 16 PCIe connector sites




Validation Platform to Characterize Standalone Oscillators in Various Package Sizes





DAUGHTER CARD IMPLEMENTATION





- 2 Supply Options:
 - LDO Mode Using 1 Configurable LDO to powerup 4 devices per daughter card
 - Bypass Mode Directly powering-up the devices from main supply
- 4 devices can be accommodated on the daughter card
- Soldered and Socketed version supported
- Different daughter card variants to support 4 package sizes
 - 1.6x1.2mm, 2.0x1.6mm, 2.5x2.0mm, 3.2x2.5mm
- All Clock Out Traces are 50ohm impedance controlled

Validation Platform to Characterize Standalone Oscillators in Various Package Sizes

N CONNECTING

ADVANTAGES OF MOTHER BOARD – DAUGHTER CARD SETUP

- Scalable and flexible:
 - Setup is flexible in handling 4 different packages at the same time + combination of soldered and socket variant of board
- Ease of Manufacturing:
 - Only manufacture Daughter cards which makes it cost efficient. Cost savings of ~48%
- Ease of Device Handling and Debug:
 - Optimize time taken to mount and remove devices from sockets
 - Debugging and probing signals become easier with daughter cards
- Reduced reflow stress:
 - Smaller daughter cards can sustain multiple solder reflows, unlike bigger boards which result in sagging thereby causing mechanical stress



Validation Platform to Characterize Standalone Oscillators in Various Package Sizes



LIMITATIONS OF MULTISITE SETUP


- Current measurement of individual devices
- Signal Integrity issues as clock path routes has a lot of via transitions / stubs
- Noise floor degradation prevents precise Jitter measurement
- Site to Site variations after multiple usage of board due to warpage, wear & tear etc.




/alidation Platform to Characterize Standalone Oscillators in Various Package Sizes

25 moresary


Precision Test Equipment






RESULTS: AGING SETUP

 Setup depicting Aging measurements done on multiples devices (64) in one go








Validation Platform to Characterize Standalone Oscillators in Various Package Sizes

IMPACT ON AGING DATA WITH OVEN





Oven Temperature Variation

Impact of Oven temperature variations on frequency stability

- Temperature Chamber has inherent variation of ~0.8deg. Observed temperature control is sensitive to change in ambient.
- Frequency ppm variations in oven correlates with the temperature variations
- Recommended setup for Aging: <u>Oil Bath</u> since temperature variations are controlled




Validation Platform to Characterize Standalone Oscillators in Various Package Sizes

25 moresary

17

RESULTS: DC PARAMETERS

- Setup depicting DC measurements across 4 different package types
- Entire Mother Board+ D Card is placed in a Thermal Chamber and 64 units tested sequentially across Temperature





+100.143 Ω

Daughter Cards
4 of each package.
16 units per package
64 units in total

Validation Platform to Characterize Standalone Oscillators in Various Package Sizes

Session 3

CONCLUSION

- In this paper, we present to you TIs BAW Based Oscillators and bench validation platform to characterize the same
 - High Performance Oscillators
 - Low Power Oscillators
- We discuss the critical aspects of bench validation and how to guarantee datasheet spec by characterization through extensive coverage
- Single Site and Multi Site Test Setups are needed to cover different types of parameters, some being performance oriented and some are statistical in nature
- Results of various parameters measured with different setups are shown



Validation Platform to Characterize Standalone Oscillators in Various Package Sizes



COPYRIGHT NOTICE

The presentation(s) / poster(s) in this publication comprise the Proceedings of the TestConX 2024 workshop. The content reflects the opinion of the authors and their respective companies. They are reproduced here as they were presented at the TestConX 2024 workshop. This version of the presentation or poster may differ from the version that was distributed at or prior to the TestConX 2024 workshop.

The inclusion of the presentations/posters in this publication does not constitute an endorsement by TestConX or the workshop's sponsors. There is NO copyright protection claimed on the presentation/poster content by TestConX. However, each presentation / poster is the work of the authors and their respective companies: as such, it is strongly encouraged that any use reflect proper acknowledgement to the appropriate source. Any questions regarding the use of any materials presented should be directed to the author(s) or their companies.

"TestConX", the TestConX logo, the TestConX China logo, and the TestConX Korea logo are trademarks of TestConX. All rights reserved.

www.testconx.org