


A Contact Remembers: Property Changes after Pulse Current Loading

Gert Hohenwarter
GateWave Northern, Inc.



Mesa, Arizona • March 2–5, 2025



TestConX 2025

Problem

- During and after high current loading in contact characterization testing has been observed that contact properties such as C_{res} and maximum current carrying capacity may change
- An examination of significance and cause of such changes appears desirable



A Contact Remembers: Property Changes after Pulse Current Loading

2

2025

TestConX 2025

Approach

- Identify some changes by processing a large number of test data from existing tests
- Conduct a series of targeted tests
- Record changes after first and second passes of tests for the same contact under undisturbed DC and position conditions
- Examine variability after pulse current loading
- Examine variability after further mechanical actuation



A Contact Remembers: Property Changes after Pulse Current Loading

3

2025

TestConX 2025

Test sequence


- Set up test environment and run DC test:
 - Establish nominal mechanicals and begin with 0 drive current
 - Slowly increase drive current level until the maximum allowable temperature increase dT_{max} is reached
- Repeat this test without disturbing contact mechanically
- Repeat this test after actuating the contact mechanically



A Contact Remembers: Property Changes after Pulse Current Loading


4 **2025**

Test setup




Data Evaluation


- Acquire the following example graphs as a function of current:



Voltage and resistance



Derivative of power v. current



Temperature rise



TestConX 2025

Data evaluation: Determination of Current Carrying Capacity

- Find CCC from data at a set temperature increase
 - (over ambient or other selected test temperature)
- Typical temperature rise: 20 °C
- Not a (serious) problem at DC, but different for pulse current loading



A Contact Remembers: Property Changes after Pulse Current Loading

7 **2025**

TestConX 2025

Data evaluation:

CCC and time constant τ examples

- CCC example for several duty cycles

	DC	50%	25%	10%	1%	
I_{max}	2.58	3.50	4.36	5.27	6.22	A

- Low thermal mass together with heat sinking of the contact at either end typically leads to a low (millisecond) thermal time constant τ , which frequently is comparable to the 300 millisecond pulse length used in test here



A Contact Remembers: Property Changes after Pulse Current Loading


8

2025

TestConX 2025

Background: Power developed in contact


- Power developed in the contact $P = I^2 * R$



It is evident that despite relatively low resistance power levels in a contact can reach significant values

Background: Temperature rise (computed)

2mm long contact, cross-section = 4.0 mils²



Temperature rise in the contact becomes an issue at higher current levels



Test/evaluation questions of interest

- Does something happen ?
- What happens ?
- What change(s) occur(s) ?
- Are changes reversible ?
- Possible causes
- Significance of changes



A Contact Remembers: Property Changes after Pulse Current Loading


11

2025

TestConX 2025

DC I_{max} change examples

10 successive tests of 1 contact - DC only, contact type 1



After the initial test max current increases more or less steadily
 Possible cause: Reduction of interface resistance
 Mechanical actuation increases that change (D2, D4)




A Contact Remembers: Property Changes after Pulse Current Loading

12 **2025**

TestConX 2025

DC I_{max} change examples

10 successive tests of 1 contact - DC only, contact type 2



After the initial test max current increases more or less steadily
 Possible cause: Reduction of interface resistance
 Mechanical actuation increases that change (D6)




A Contact Remembers: Property Changes after Pulse Current Loading

13 **2025**

TestConX 2025

DC I_{max} change example

DC after complete test sequence w. pulse, contact type 1, unactuated



Significant increases of max current is apparent


Possible cause: Reduction of interface resistance

High current exposure initially continues to increase that change from test to test



DC I_{max} change example

DC after complete test sequence w. pulse, contact type 1, unactuated



Significant increases of max current is apparent

Possible cause: Reduction of interface resistance


High current exposure initially continues to increase that change from test to test

DC1, DC2 are successive tests (after pulsing, but w/o pulse)



DC I_{max} change example

DC after complete test sequence w. pulse, contact type 1, actuated



Steady increase of max current is apparent

Possible cause: Reduction of interface resistance

Pulsing and mechanical actuation continue to increase the change from test to test


DC1, DC2 are successive tests (after pulsing, but w/o pulse)



TestConX 2025

Pulsed I_{max} change example

CCC after complete test sequence w. pulse, contact type 1, unactuated



Some increase of max current is apparent

Possible cause: Reduction of interface resistance

Peak pulse current levels during test increased with decreasing duty cycle




A Contact Remembers: Property Changes after Pulse Current Loading

17 **2025**

Pulsed I_{max} change example

CCC after complete test sequence w. pulse, contact type 1, actuated



Some increase of max current is apparent, actuation reduces scatter
 Possible cause: Reduction of interface resistance
 Peak pulse current levels during test increased with decreasing duty cycle



A Contact Remembers: Property Changes after Pulse Current Loading

18 **2025**

TestConX 2025

Additional observations during testing

- Data presented on the following slides will show the measured temperature rise (or change thereof) for a given drive current
- This is also an indicator of contact resistance C_{res} and CCC change (C_{res} includes the contact interfaces)
- An *increase* in **temperature rise** for a given current means an *increase* in **C_{res}** and a *decrease* in **CCC**





A Contact Remembers: Property Changes after Pulse Current Loading

19

2025

TestConX 2025

Temperature rise change at 0.5 A DC drive



High contact force

Low contact force

Test #

10 successive tests of 1 contact, **single piece** construction

Repeated tests on same contact (**without** actuation)




A Contact Remembers: Property Changes after Pulse Current Loading


20

2025

Temperature rise change at 0.5 A DC drive



Day 1



Day 2

Test #

10 successive tests of 1 contact, **single piece** construction

Repeated tests on same contact (**without** actuation)




A Contact Remembers: Property Changes after Pulse Current Loading


21

2025

Temperature rise change at 0.5 A DC drive



Day 1



Day 2

Test #

10 successive tests of 1 contact, **single piece** construction

Repeated tests on same contact (**with** actuation)




A Contact Remembers: Property Changes after Pulse Current Loading


22

2025

Temperature rise change at 0.5 A DC drive



Day 1



Day 2

Test #

10 successive tests of 1 contact, **multi-piece** construction

Repeated tests on same contact (**without** actuation)




A Contact Remembers: Property Changes after Pulse Current Loading

23


2025

TestConX 2025

Temperature rise change at 0.5 A DC drive



Day 1



Day 2

Test #

10 successive tests of 1 contact, **multi-piece** construction

Repeated tests on same contact (**with** actuation)




A Contact Remembers: Property Changes after Pulse Current Loading

24

2025

Temperature rise change at 1 A DC drive

$$(dT2-dT1)/dT1 \text{ in } \%$$



10 successive tests of 2 contacts

Test #


Full test sequence inclusive pulse testing



A Contact Remembers: Property Changes after Pulse Current Loading

25 **2025**

Temperature rise change at max. current



220 tests of 110 different contacts:

difference between successive tests on same contact after pulse testing
(without actuation)



A Contact Remembers: Property Changes after Pulse Current Loading

26 **2025**

TestConX 2025

Comments

- It appears that pulse current testing often results in higher CCC and reduced Cres after exposure of a contact to high current levels despite the short pulse length
- In cases of reduced CCC it is possible that contact force reduction was an issue
- It must be assumed that the actual temperature in parts of the contact structure exceeds the recorded value (this has been demonstrated to some extent elsewhere with quasi-optical temperature sensing).



A Contact Remembers: Property Changes after Pulse Current Loading

27

2025

Conclusion

- Pulse current testing alters observed CCC after exposure to high current levels despite short pulse lengths
- Since changes observed during limited temperature rise testing appear reversible it may be suspected that the primary cause of change is due to the contact interface
- Any impact of this on the test floor is likely to be application specific and must be gauged by the end user
- Bulk property changes were not conclusively observed but may become an issue at testing to higher temperature rise levels and possible destruction.



A Contact Remembers: Property Changes after Pulse Current Loading

28

2025

Presentation / Copyright Notice

The presentations in this publication comprise the pre-workshop Proceedings of the 2025 TestConX workshop. They reflect the authors' opinions and are reproduced here as they are planned to be presented at the 2025 TestConX workshop. Updates from this version of the papers may occur in the version that is actually presented at the TestConX workshop. The inclusion of the papers in this publication does not constitute an endorsement by TestConX or the sponsors.

There is NO copyright protection claimed by this publication. However, each presentation is the work of the authors and their respective companies: as such, it is strongly encouraged that any use reflect proper acknowledgement to the appropriate source. Any questions regarding the use of any materials presented should be directed to the author/s or their companies.

The TestConX logo and 'TestConX' are trademarks of TestConX.