

Column Replaceable Elastomer Socket

BH Kim, YC Nam, DH Roh, Josh Choi
TSE Co., Ltd



Mesa, Arizona • March 2-5, 2025



TestConX 2025

Contents

- Structure and Limitations of Conventional Elastomer
- ELTUNE-air : Overcome Limitations of Conventional Elastomer
- Structure of ELTUNE-air
- Advantages of ELTUNE-air
- Comparison of Properties with Conventional Elastomers
- Summary



Column Replaceable Elastomer Socket


2 **2025**

TestConX 2025

Structure and Limitation of Conventional Elastomer

➤ Structure and Limitations of Conventional Elastomer Socket (1)

- When testing, Warpage of the Device repeatedly exerts greater pressure on the certain column, weakening elasticity and ultimately accelerating the depression of specific column
- Unlike Pogo sockets, conventional elastomers cannot replace damaged specific columns, requiring the replacement of the entire socket




TestConX 2025

ELTUNE-air : Overcome Limitations of Conventional Elastomer

➤ Column Replaceable Elastomer Socket

- ELTUNE-air – Each Columns of ELTUNE-air are surrounded by air, giving them an independent structure, which enables individual replacement even in the event of depression or damage




TestConX 2025

Structure and Limitation of Conventional Elastomer

➤ Structure Limitations of Conventional Elastomer Socket (2)

- Since all Columns are surrounded by a silicon mold, challenging to achieve the organic movement of individual columns like Pogo Socket
- When testing a device with large Warpage, the outer edges of the device over-stroke the column, while the central area suffers from insufficient stroke, leading to unstable test results.




TestConX 2025


ELTUNE-air : Overcome Limitations of Conventional Elastomer

➤ Structurally independent Column Formation


- ELTUNE-air, capable of overcoming the disadvantages of conventional elastomers, enables the organic movement of individual columns.
- By utilizing an Air gap, ensure to avoid interference between columns when contacting with Device with warpage



Structure of ELTUNE-air



[Section View]




[Top View]

TestConX 2025

Advantage of ELTUNE-air

➤ Advantage 1. Individual Column Replacement

- Conventional Elastomer need to replace whole Socket if even a single column becomes defective
- Individual column replacement provides advantages in terms of maintenance and cost saving





TestConX 2025


Advantage of ELTUNE-air

➤ Advantage 2. Increased Life-Span

- When testing devices with Warpage, structural characteristics cause larger deformation in the outer column
- The air-gap structure in ELTUNE-air convert over-strokes into linear compression, minimizing damage



< Normal Elastomer Socket >




< ELTUNE-Air Socket >

TestConX 2025


Advantage of ELTUNE-air

➤ Advantage 3. Low Force

- Able to overcome Max force limitation of Handler through Low force of Socket
- When contacting, Air gap distributes the force, enabling low force
- Stable testing is possible with approximately 20% of the force compared to conventional sockets



< Conventional Elastomer Socket >



< ELTUNE-air Socket >



TestConX 2025

Advantage of ELTUNE-air

➤ Advantage 4. High Speed Performance

- The dielectric constant of the dielectric material surrounding the existing column ranges from 3 to 5, which limits the improvement in SI
- ELTUNE-air, the dielectric surrounding the column is air (dielectric constant of 1), providing an advantage of high SI
- Due to the matching of characteristic impedance (Z_0), the lower the dielectric constant (ϵ_0) value, the better the Signal Integrity (SI) characteristics
 - ✂ Target : IL : 20% ↑, RL : 10% ↑, Z_0 : 10% ↑

$$Z_0 \approx \sqrt{\frac{L}{C}} = \sqrt{\frac{\mu}{\epsilon}} \ln\left(\frac{d}{a}\right) / \pi$$



 TestConX™

Column Replaceable Elastomer Socket


11 **2025**

TestConX 2025

Comparison : Conventional Elastomer vs ELTUNE-air

➤ Contact Resistance

- When measuring CRES Pkg with Warpage, ELTUNE-Air shows consistently lower CRES values compared to the conventional elastomer socket




TestConX 2025

Comparison : Conventional Elastomer vs ELTUNE-air

➤ Contact Resistance (Variance)

- From the graph data, ELTUNE-air shows superior CRES characteristics, particularly with reduced Min and Max variation, indicating much more uniform bump characteristics




TestConX 2025

Comparison : Conventional Elastomer vs ELTUNE-air

➤ Contact Resistance (Life Span)

- ELTUNE-Air shows superior CRES characteristics during 100K touchdowns




Column Replaceable Elastomer Socket

14 **2025**

Comparison : Conventional Elastomer vs ELTUNE-air

➤ Contact Force

- ELTUNE-Air shows 20% Lower Force at recommended stroke



Stroke(um)		50	100	150	200	250	300	350	400	450
Force/Bump (gf)	Conventional Elastomer	0.40	0.96	2.59	3.74	5.91	8.49	12.30	17.97	24.87
	ELTUNE-Air	0.32	0.78	2.15	3.18	4.94	7.00	9.38	14.64	20.06



Column Replaceable Elastomer Socket

15 **2025**

Comparison : Conventional Elastomer vs ELTUNE-air

➤ Signal Integrity

- ELTUNE-Air has 39% superior Insertion Loss than Conventional Elastomer socket
- ELTUNE-Air has 16% superior Return Loss than Conventional Elastomer socket

Signal Integrity Performance	Conventional Elastomer	ELTUNE-air
Insertion Loss (dB)	<p style="text-align: center;">-0.23</p>	<p style="text-align: center;">-0.14</p>
Return Loss (dB)	<p style="text-align: center;">-13.32</p>	<p style="text-align: center;">-15.49</p>
Z_0	71Ω (85Ω±16%)	79Ω (85Ω±7%)



Column Replaceable Elastomer Socket

16 **2025**

TestConX 2025

Summary

- Introduction to ELTUNE-air Socket
→ Enhancing Existing Elastomer Limitations
- Bump with Individual Compliance
→ Advantages in CRES, low force, and SI performance
- Ideal for Testing Warped Package Devices
→ ELTUNE-air Socket is the optimal solution for Final Testing of Large Packages



Column Replaceable Elastomer Socket

17 **2025**

Presentation / Copyright Notice

The presentations in this publication comprise the pre-workshop Proceedings of the 2025 TestConX workshop. They reflect the authors' opinions and are reproduced here as they are planned to be presented at the 2025 TestConX workshop. Updates from this version of the papers may occur in the version that is actually presented at the TestConX workshop. The inclusion of the papers in this publication does not constitute an endorsement by TestConX or the sponsors.

There is NO copyright protection claimed by this publication. However, each presentation is the work of the authors and their respective companies: as such, it is strongly encouraged that any use reflect proper acknowledgement to the appropriate source. Any questions regarding the use of any materials presented should be directed to the author/s or their companies.

The TestConX logo and 'TestConX' are trademarks of TestConX.